


volkano

BOOMERANG SERIES



USER'S MANUAL

Please read and retain these instructions
for future use.

HIGHLIGHTS:

Lightweight and comfortable to wear.
Built-in microphone.

PRODUCT SPECIFICATIONS:

Model: VB-508-BK

Bluetooth Version: V4.0

Supported Profiles: HFP, HSP, A2DP, AVRCP, APTX

Usage Distance: 10m

Battery Capacity: 60mAh

Stand-by Time: >100 hours

Talk Time: 4 Hours

Power Input: DC5V/200mA

Charge Time: 2 Hours

This product is compatible with most devices that have Bluetooth: Mobile phone, Tablet, iPads, PC.



- + ————— • Volume Up
- ————— • Universal switch
Telephone Answering Key
- ————— •
- ————— • Volume Down



SAFETY PRECAUTIONS:

1. Do not listen to loud music for extended periods of time.
2. Do not use these earphones when performing tasks that require your full attention, like driving.
3. Not intended for use by children. Keep out of reach of children.
4. These earphones are sweat proof, however, they are not water resistant.
5. Do not submerge in water or allow the earphones to become wet.
6. Stop using the earphones should you experience any discomfort, irritation or have any adverse reaction caused by use.
7. Do not store the earphones or use the earphones in temperatures below 15 °C or above 55 °C.



INSTRUCTIONS FOR USE.

PLEASE NOTE: Basic functions may vary from Bluetooth device to Bluetooth device.

ON/OFF: press and hold the SQUARE Key for 5 seconds to turn on or off.

PAUSE PLAYBACK: Press the SQUARE Key to pause playback, and press again to resume.

ANSWER / END CALL: Press the SQUARE key to answer a call, and press again to end.

REJECT A CALL: Press and hold the SQUARE key for about 2 seconds to reject call.

SELFIE SHUTTER: While paired to a device with a camera, close all music applications and press the "+" Key twice to use your earphones as a remote shutter.

PAIRING YOUR EARPHONES:

1. Ensure the distance between the Bluetooth device and the earphones is within 1m.
2. Press and hold the SQUARE key for about 5 seconds, releasing only when blue and red lights flash alternatively. Flashing lights indicates pairing mode.
3. Enable the Bluetooth function of your device and search for the earphones in the list of discovered items. Click on the earphones to pair. Should the connection be successful, the blue light will flash slowly.



DIAGRAM DRAWING:

NOTE:

1. You do not require a password to pair these earphones to a device, however, older models of Bluetooth may ask you for a password. Please enter "0000" should this happen.
2. The pairing mode will be active for 5 minutes. Should pairing fail after 2 minutes, the earphones will automatically enter stand-by mode.
3. After pairing is completed, the headphone will recall the Bluetooth device it last connected to, and re-connect automatically when next used.

