VX GAMING

SALVO
SERIES

BACKLIT GAMING KEYBOARD

INSTRUCTION MANUAL

Please read these instructions carefully and retain for future reference.

VX Gaming by:

volkano

MODEL: VX-102-BK

Features:

- Three colour LED backlight mode (Blue, Red and Purple) with 4 brightness settings and an illuminating feature.
- WIN key lockable for more fluent gaming.
- Compact and quick responsive keys.
- Non-slip multimedia keys for the best gaming performances and comfort.
- Strengthened spacebar for maximum lifetime and long hours of gaming.
- Large comfortable palm rests effectively reduces hand fatigue.

Specifications:

- USB version: 2.0
- Keyboard size: 458.5 (L) x 190 (W) x 30 (H) mm
- Keyboard weight: 683g
- Number of keys: 104
- Multimedia keys: 6 (to use with Fn key)
- Key travel: 2.0mm
- Key force: 50 +/- 5g
- Rated voltage/current: DC 5V/250mA

Layout:

1. Fn key (function button)
2. NumPad8
3. NumPad5
4. NumPad2

To use multimedia function keys, press and hold the Fn key, and then press the function key or corresponding number pad key.



Adjust LED brightness
There are 4 LED brightness modes: pulse mode with 100% brightness, 100% brightness, 50% brightness mode and lights out mode.

- Press Fn+Pad8 to increase brightness and switch among 4 LED modes.
- Press Fn+Pad2 to decrease brightness and switch among 4 LED modes.

Lock and Unlock WIN key
- Press Fn+Pad12 to lock WIN key for gaming mode, WIN key function will be disabled.
- Press Fn+F12 again to unlock WIN key, WIN key function will be enabled.

Safety precautions:
Please read these instructions carefully and use the device according to the procedures described in this manual. Failure to do so could result in damage or may cause your warranty to become void.

- The product may only be used with the parts provided by the manufacturer.
- Always keep the device away from water or other liquids.
- Always make sure your hands are dry before using this device.
- Do not expose this device to high temperatures, direct heat, or direct sunlight.
- Do not cover the device. i.e: use beneath pillows, blankets or under papers.
- Do not drop, bend or puncture the device.

Environmentally friendly disposal:
Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well being.